

# PINNACLE SL600HD

## HEAVY DUTY STAIRLIFT



### THE INDUSTRY'S ONLY 600 LB CAPACITY STAIRLIFT

High-backed, contoured extra wide seat ensures a comfortable and secure ride. Sturdy, stationary armrests and reinforced footrest add stability for safer transfers. The seat slides out from the wall as it pivots at the top and bottom landings.

As with all Pinnacle stairlifts, the HD model is engineered to the highest industry standards and designed for optimal comfort, convenience, and aesthetics.

The patented nylon polymer worm gear provides low friction for longer battery operation during a power outage and the elimination of maintenance related to track lubrication providing extra peace of mind.



### UNIQUE SLIDE-SWIVEL SEAT

High capacity seat pivots 85° as it slides away from the wall to allow for installation closer to the wall and easier dismount at the top and the bottom of the stairwell.

# COMFORT AND PERFORMANCE



*I can safely access the upper level of my home with my stairlift. It allows me to move comfortably in and out of my chair with its swivel seat and sturdy armrests.*

## SL600HD PRODUCT SPECIFICATIONS

<b>WEIGHT CAPACITY</b>	600 lb	<b>FOLDED WIDTH</b>	16.5" from wall
<b>TRACK LENGTH</b>	15' 6" to 40'	<b>SPEED</b>	14 FPM
<b>SEAT SIZE</b>	18.5" x 14"	<b>BACKREST SIZE</b>	17.6" x 17"
<b>INCLINE LIMITS</b>	27° to 48°* * inclines above 45° may require local jurisdiction approval.	<b>DRIVE</b>	- Patented nylon polymer gear rack - Helical worm gear
<b>SAFETY FEATURES</b>	- 85° seat swivel interlock - Centrifugal overspeed brake - Footrest obstruction sensors - Lockable battery + breaker switch - Motor brake - Obstruction sensors - Seat belt	<b>CERTIFIED</b>	- ETL listed - CSA B44.1/ASME A17.5 - Safety standard ASME A18.1 - Rated commercial and residential
<b>OPTIONS</b>	- Key lock - Extra rail - Manual lowering tool	<b>WARRANTY</b>	- 3-year parts - 10-year gear rack - 1-year battery